



Warning: Before installation, commissioning, and operation, ensure that the pressure transmitter is suitable for the application in terms of measuring range, design and environmental conditions. Non-observance can result in serious injury and/or damage to equipment.

Intended use: This instrument converts pressure into an electrical signal.

The instrument has been designed and built solely for the intended use described here and may only be used accordingly. If the equipment is used in a different manner, the protection provided by the equipment may be impaired and Trafag shall not be liable for any claims at all.

Datasheets

DPC 8380




www.trafag.com/H72320

DPS 8381



www.trafag.com/H72321

Type label description (example)




Electrical connections


Designation	M12x1 5-pol.	M12x1 4-pol.
Ambient temperature range	-25°C ... +85°C	-25°C ... +85°C
UL-rated ambient temperature range	-20°C ... +80°C	-20°C ... +80°C
Type code	838X.XX.XXXX.35	838X.XX.XXXX.32
Pin configuration		

Output	I_{SUPPLY}	U_{SUPPLY}
4 ... 20 mA	≤ 30 mA	15 ... 30 VDC
0 ... 10 VDC	≤ 30 mA	15 ... 30 VDC
0 ... 5 VDC	≤ 30 mA	15 ... 30 VDC
1 ... 6 VDC	≤ 30 mA	15 ... 30 VDC


Connection of the measuring equipment




*) The use of a shielded cable is recommended





Connection of loads to switching output



Switching output functions




Dimensions



Mounting

Tighten the device



Display indication

	Description
OL	The measured pressure is >3% above the measuring range end-point → The indication disappears as soon as the pressure is reduced again
UL	The measured pressure is >3% below the measuring range zero-point → The indication disappears as soon as the pressure is reduced again
Perr	Signal processing is faulty. → Please replace measuring device
FALS	Incorrect access code → Enter the correct access code
Sbrk	Sensor break; the sensor element is defective. → Please replace the pressure measuring device
Fi2c	Internal device communication is interrupted → Please replace the pressure measuring device
Ecrc	Internal memory damage occurred → Execute a factory reset. If the recovery is not successful, replace the pressure measuring device
FE2P	Internal memory damage occurred → Execute a factory reset. If the recovery is not successful, replace the pressure measuring device
EnFc	NFC communication was not successful → Try again to communicate again. If the error persists, replace the pressure measuring device
E.0FC	Zero-set out of range The measured pressure value is outside of the valid range for the zero-set function → Press [Enter] ↵ on the measuring device to reset the error indication This error indication does not appear when performing the zero-set function by means of the Sensor Master App (Android smartphone)

Parametrisation


The display pressure switches DPC 8380 and DPS 8381 can be parametrised either with the 3 buttons on the display and the menu navigation on page 4 of this instruction, or via Sensor Master App installed on a NFC capable Android smartphone.

Android App Trafag Sensor Master




With the free Android app „Trafag Sensor Master“, available in the Google Play Store, the parameters of the Trafag display pressure transmitter DPS 8381 and DPC 8380 can be set very simply through a smartphone. In addition to a variety of parameters for the switch points, the measurement range can be scaled. Communication is conducted via the NFC interface on the display. Through this interface, the measurement values of the internal data logger can also be read out and then processed further via smartphone.


Download the Android app in the Google Play Store



Operating menu



¹⁾ optional function package
²⁾ P_EP - P_nP ≥ 50 % FS



By pressing ▲ + ▼ simultaneously
the menu will return to the
base display or automatically
after ca. 60 s without operation.



pw* When performing a parameter change by pressing
▲ or ▼ and if an access code has been defined, it has to
be entered digit by digit.
After confirming the new parameter value, the menu
item of the changed parameter will be displayed.